



DATE: 2018-05-09

MODEL: SR1

SR1 HANKOOK SETUP – REAR UPRIGHT BOLT SPACERS

PRIORITY –HIGH (ACTION)

Following the change of tyres to Hankook and the subsequent setup recommendations we will also now mandate that all cars that have fitted the longer damper eyelets, now also fit spacers on the rear upright bolt. This allows for increased droop to be achieved. Spacers should be fitted above and below the rose joint as shown below.



Figure 1 - Rear upright bolt with spacers

The part number for the spacers is SU0050

For parts supply please contact: stores@radicalsportscars.com

Technical Department
Radical Sportscars

Mobile: +44 (0)7876 146854
Tel: +44 (0)1733 331616 ext. 263
Email: technical@radicalsportscars.com



RADICAL