



DATE: 2018-05-21

MODEL: SR1

SR1 FRONT AVO DAMPER BUSHES

PRIORITY –HIGH (ACTION)

Customers are advised to check their front Avo dampers to ensure the lower wishbone mounting bush has the correct steel bushing inserted. The correct inner diameter should be 10.0mm



If found to be incorrect please contact our stores department for a FOC replacement that can be reinserted. The part number for the correct bush is SS0206.

For parts supply please contact: stores@radicalsportscars.com

Technical Department
Radical Sportscars

Mobile: +44 (0)7876 146854
Tel: +44 (0)1733 331616 ext. 263
Email: technical@radicalsportscars.com



RADICAL